Kullanım Talimatları

• Türkçe

UNIVERSAL KLİMA UZAKTAN KUMANDASI

---Bazı Markalar Eşleştirme Gerektirmez ---

Fabrika ayarı olarak bazı klimalar önceden ayarlanmıştır:
Gree\Midea\Mitsubishi\Toshiba\Chunlan\Haier\Hualing. Varsayılan markalar eşleştirme ayarları olmadan doğrudan kullanılabilir.
(Bazı modeller fabrika ayarlı kodla çalışmayabilir, bu durumda lütfen A/B/C/D yöntemlerini izleyerek uzaktan kumandanızın kodunu ayarlayın)

---Çoklu Eşleştirme Yöntemleri ---

Kodu eşleştirmek için aşağıdaki A/B/C/D yöntemlerinden birini seçebilirsiniz.

A> MARKA DÜĞMESİ

1. Klimanın gücünü açın, uzaktan kumandayı klimanın alıcısına doğru çevirin;
2. İlgili markanın CODE tuşuna ve ilgili marka için belirlenmiş düğer düğmeye uzunca basılı tutun. Örneğin: Midea markası için "CODE" ve "TEMP▲" tuşuna basılı tutun. BİP sei geldiğinde bırakın;
3. Düğmelerin çalışıp çalışmadığını kontrol edin. Doğruysa, kod geçerlidir. Değilse, lütfen
2-3. Adımları tekrarlayın.

Marka koduna karşılık gelen düğmeler:

ON/OFF	GREE/ HAIER	TEMP+	MIDEA/ TOSHIBA/ CHANGHONG	TEMP-	SHARP/ KELON
WIND	MITSUBISHI/ OTHERS	MODE	LG/MI/ SUMSUNG/ SKYWORTH	M.SWING	HITACHI/ PANASONIC
A.SWING	SANYO/ HISENSE	TIME ON	CHIGO/ DAIKIN	TIME OFF	FUJITSU/ CARRIER
FAST HOT	CHUNLAN/ AUX	FAST COOL	SHINCO/ AUCMA		

B> OTOMATİK ARAMA

1. Klimanın gücünü açın, uzaktan kumandayı klimanın alıcısına doğru çevirin;
2. Tip kodu birer birer değişene kadar "SET" düğmesini basılı tutun (yaklaşık 6 saniye), şimdi hızlı arama modunda, klimanızın durumunu kontrol edin. Klimanızdan bir tepki geldiğinde herhangi bir düğmeye basarak aramayı durdurabilirsiniz.
* Eğer hızlı geçtiyseniz; kodu teker teker artırıp azaltmak için "TEMP▲" ve "TEMP▼" düğmelerini kullanabilirsiniz
3. Eğer kodun doğru olduğunu düşünüyorsanız, ayarı tamamlamak için "OK" düğmesine basın; değilse, Aramaya devam etmek için "SET" düğmesine basın.

C > MANUEL KOD GİRİŞİ

1. Kullanma kılavuzundaki "KOD TABLOSU"na bakarak kendi klimanızın kodunu bulun. Örneğin: HAIER:001. Klimanın gücünü açın, uzaktan kumandayı klimanın alıcısına doğru çevirin;
2. "SET" düğmesini yaklaşık 3 saniye basılı tutun, tip kodu ekranda yanıp sönmeye başlayınca bırakın;
3. İstediğiniz kodu bulana kadar "TEMP▲" ve "TEMP▼" düğmelerine teker teker basın, kodlar birer birer artıp azalır. Hızlı ilerleyip atylamak için aynı düğmelere uzunca basabilirsiniz;
4. Çıkmak için "OK" düğmesine basın, diğer düğme işlevlerinin doğru olup olmadığını kontrol edin. Doğruysa, ayarı tamamlayın; değilse, bir sonraki kod setini ayarlamaya devam etmek için lütfen 1-4 adımlarını tekrarlayın.

D> MANUEL KOD ARAMA

1. Klimanın gücünü açın, uzaktan kumandayı klimanın alıcı penceresiyle hizalayın.
2. "SET" düğmesini yaklaşık 3 saniye basılı tutun, tip kodu ekranda yanıp sönmeye başlayınca bırakın;
3. "TEMP▲" veya "TEMP▼" düğmesine tek tek basın, klimanızın durumunu kontrol edin ve klima yanıt verdiğinde çıkmak için "OK" düğmesine basın.
4. Diğer düğme işlevlerinin doğru olup olmadığını kontrol edin. Doğruysa, ayarı tamamlayın; doğru değilse, bir sonraki kod setini ayarlamaya devam etmek için lütfen 1-4 adımlarını tekrarlayın.

---Ek Fonksiyonlara İlişkin Talimatlar---

1. Saat işlevi:

1> Saat ayarına girildiğini gösteren ilgili rakam yanıp sönmeye başlayana kadar "CLOCK" tuşuna basılı tutun.

2> "TEMP▲" ve "TEMP▼" tuşlarına basıldığında dakika 1 artıp azalır. 2 saniye basılı tutulduğunda artırma ve azaltma işlemine devam edilebilir.

3> Ayar yapıldıktan sonra saat ayarından çıkmak için "OK" tuşuna basınız.

2. TIME ON/OFF (ZAMAN AÇMA/KAPAMA) fonksiyonu: (Orijinal klimada zamanlama fonksiyonu olması gerekmektedir, aksi takdirde buton geçersizdir.)

TIME ON: Cihaz açık durumdayken, "TIME ON" butonuna her bastığınızda, süre 1 saat artacaktır;

TIME OFF: Cihaz açık durumdayken, "ZAMAN KAPALI" tuşuna her bastığınızda, süre 1 saat azalacaktır;

Zamanlamayı iptal etme: Zamanlamayı iptal etmek için "ON/OFF" düğmesine basın veya zamanlama süresi 15 saate çıktıktan sonra, TIME ON'un iptal etmek için "TIME ON", TIME OFF'u iptal etmek için "TIME OFF" düğmesine basın.

Not: TIME ON/OFF işlevi yalnızca klima açıkken ayarlanabilir ve TIME ON ile TIME OFF ayarları aynı anda yapılamaz.

3. Hızlı soğutma/Hızlı ısıtma fonksiyonu:

Soğutma modu, 21 derece, kuvvetli üfleme ve otomatik rüzgar yönünü ayarlamak için "FAST COOL" düğmesine basın;

Isıtma modu, 26 derece, kuvvetli üfleme ve otomatik rüzgar yönünü ayarlamak için "FAST HOT" düğmesine basın.

4. Sıcaklık limit fonksiyonju (enerji tasarrufu / çevreci mod)

Bu işlev, klima çalışmasının minimum veya maksimum sıcaklığını, çevre koruma gereksinimlerine uyacak şekilde sınırlar. Ayrıca enerji tüketimini azaltıp tasarruf sağlar.

Uzaktan kumanda ekranında yalnızca kullanıcının ayarladığı sıcaklık gösterilir, fakat gerçekte klimayı sizin ayarladığınız minimum veya maksimum sıcaklıklar arasında çalıştırır.

Minimum sıcaklık ayarı (soğutma modu):

1> "COOLING" moduna geçin, önce "SET" düğmesini basılı tutun ve ardından "TEMP▼" düğmesine basın, yaklaşık 3 saniye sonra ekrandaki derece yanıp sönmeye başlar ve minimum sıcaklık ayarına girer;

2> "TEMP▲" veya "TEMP▼" düğmesine tekrar tekrar basın, gerekli minimum sıcaklığı ayarlayın;

3> Çıkmak için "SET" veya "OK" düğmesine basın ve minimum sıcaklık ayarı tamamlanmış olur.

Maksimum sıcaklık ayarı (ısıtma modu):

1> "HEATING" moduna geçin, önce "SET" düğmesini basılı tutun ve ardından "F.Heat" düğmesine basın, yaklaşık 3 saniye sonra ekrandaki derece yanıp sönmeye başlar ve maksimum sıcaklık ayarına girer;

2> "TEMP▲" veya "TEMP▼" düğmesine tekrar tekrar basın, istediğiniz maksimum sıcaklığı ayarlayın;

3> Çıkmak için "SET" veya "OK" düğmesine basın ve maksimum sıcaklık ayarı tamamlanır.

Not: Fabrika varsayılan ayarı, soğutma modunda minimum sıcaklık için 23 derece ve ısıtma modunda maksimum sıcaklık için 23 derece.

Sanal sıcaklık farkı ayarları:

* Önce "SET" düğmesini basılı tutun ve ardından "A.SWING" düğmesine birlikte basın, ekrandaki sıcaklık rakamı yanıp söndüğünde bırakın. Sıcaklığı ayarlamak için "TEMP▲" veya "TEMP▼" düğmesine basın.

Sıcaklık farkı aralığı 0-14 derecedir. Ayarı onaylamak için "OK" tuşuna basın. Varsayılan sanal sıcaklık değeri 3 derecedir.

Örnek: Soğutma modunda, ayarlanan minimum sıcaklık 23 derece ise, sanal sıcaklık değeri 3 derece olduğunda, kumandada gösterilen minimum sıcaklık 20 derece olacak, klimanın gerçek çalışma sıcaklığı ise 23 derecede kalacaktır.

5. Çocuk kilidi

Bu işlevi ayarlayarak, kod ayarı ve sıcaklık aralığı sınırı işlevleri kilitlenecektir.
Kilitleme/Kilidi Açma: "SET" tuşuna basılı tutun ve ardından kilitlemek veya kilidi açmak için 3 saniye boyunca "TIME OFF" tuşuna birlikte basın.

Kilitli olduğunda LCD'de "Lo" simgesi görüntülenir; Kilit açıldığında LCD'de "nL" simgesi görüntülenir.

---Fabrika Ayarlarına Geri Dön---

"SET" tuşuna basılı tutun, ardından "FAN" tuşuna yaklaşık 3 saniye basın, LCD ekran tamamen geri geldiğinde uzaktan kumanda fabrika ayarlarına geri dönmüş olur.

Instructions For Use

• English

UNIVERSAL A/C REMOTE CONTROL

---Some Brands Require No Pairing---

The remote control has been set default code before the factory, the factory code can be directly applied to most of the different models of air conditioner brands: Gree\Midea\Mitsubishi\Toshiba Chunlan\Haier\Hualing in the market. The default brands can be used directly without pairing settings. (Some models may not work with the factory-set code, so please set the code of your remote control by following A/B/C/D method.)

---Multiple Paring Methods Available---

You can choose one of the following A/B/C/D methods to match the code.

A> BRAND BUTTON

1. Switch on the power of the air conditioner, align the remote control with the receiving window of the air conditioner;
2. Long press the corresponding brand CODE button, for example: Midea brand corresponding to "TEMP▲", release the button until the air conditioner begins to automatically run with a "beep" sound, and the setup is finished;
3. Check the function of the buttons whether working or not. If correct, the code is valid. If not, please repeat Steps 2-3.

Brand code corresponding button

ON/OFF	GREE/ HAIER	TEMP+	MIDEA/ TOSHIBA/ CHANGHONG	TEMP-	SHARP/ KELON
WIND	MITSUBISHI/ OTHERS	MODE	LG/MI/ SUMSUNG/ SKYWORTH	M.SWING	HITACHI/ PANASONIC
A.SWING	SANYO/ HISENSE	TIME ON	CHIGO/ DAIKIN	TIME OFF	FUJITSU/ CARRIER
FAST HOT	CHUNLAN/ AUX	FAST COOL	SHINCO/ AUCMA		

B> AUTOMATIC SEARCH

1. Switch on the power of the air conditioner, align the remote control with the receiving window of the air conditioner;
2. Press and hold the "SET" button (for about 6 seconds) until the type code has changed (+1), now it's in the mode of fast searching, checking the status of your air conditioner and press any button to pause the searching when the air conditioner responds;
* After pausing the search, you can press the "TEMP▲" or "TEMP▼" button to adjust the code number +1 or -1.
3. Check whether other button functions are correct or not (except the TEMP+/-, TIME ON/OFF, SET buttons). If correct, the code is valid, press the "OK" button to finish the setting; if not, press "SET" button to keep on searching.

C> MANUAL CODE INPUT

1. Check the corresponding brand of your A/C and its first code from the back "Code Table", find the first set of code, for example: HAIER:001; Switch on the power of the air conditioner, align the remote control with the receiving window of the air conditioner;
2. Press and hold the "SET" button for about 3 seconds, release until the type code is flickering in the window;
3. Press "TEMP▲" or "TEMP▼" button one by one until the code you need is on the window and flickering;
* Long hold down the "TEMP▲" or "TEMP▼" button, the code can be quickly adjusted.
4. Press the "OK" button to exit, check whether other button functions are correct or not. If correct, finish the setting; if not, please repeat steps 1-4 to continue setting up the next set of codes.

D> MANUAL CODE SEARCH

1. Switch on the power of the air conditioner, align the remote control with the receiving window of the air conditioner;
2. Press and hold the "SET" button for about 3 seconds, release until the type code is flickering in the window;
3. Press "TEMP▲" or "TEMP▼" button one by one, check the status of your air conditioner and press the the "OK" button to exit when the air conditioner responds.
4. Check whether other button functions are correct or not. If correct, finish the setting; if not, please repeat steps 1-4 to continue setting up the next set of codes.

---Instruction For Additional Functions---

1. Clock function:

1> Press and hold the "CLOCK" button until the corresponding number starts to flicker, indicating the clock setting is entered.

2> Press the "TEMP▲" ("TEMP▼") button will add (subtract) 1 minute, press and hold for 2 seconds can continue to add and subtract.

3> After the setting is done, press the "OK" button to exit the clock setting.

2. TIME ON/OFF function: (The original air conditioner need to have the timing function, otherwise the button is invalid.)
TIME ON: In the powered-on state, every time you press the "TIME ON" button, the timing time will increase by 1 hour;
TIME OFF: In the powered-on state, every time you press the "TIME OFF" button, the timing time will decrease by 1 hour;
Cancel timing: Press the "ON/OFF" button to cancel timing, or after the timing time increases to 15 hours, then press "TIME ON" or "TIME OFF" to cancel TIME ON or TIME OFF. Note: The time on/off function can only be set when the air conditioner is turned on, and the time on and off settings cannot be set at the same time.

3. Fast cooling/Fast heating function:

Press "FAST COOL" button to set cooling mode, 21 degrees, strong wind and auto wind direction;
Press "FAST HOT" button to set heating mode, 26 degrees, strong wind and auto wind direction.

4. Temperature range limit function: (Environmental protection function)

This function can limit the minimum or maximum temperature of the air conditioner operation to meet environmental protection needs. Beyond the limit temperature, the remote control display only shows the operating temperature, but will actually send the set minimum or maximum temperature signal.

Minimum temperature setting (cooling mode):

1> Switch to "COOLING" mode, press and hold the "SET" button first, and then press the "TEMP-" button, after about 3 seconds, the temperature on the display starts to flicker and enter the environmentally friendly minimum temperature setting; 2

> Press "TEMP▲" or "TEMP▼" button again and again, adjust to the required minimum temperature; 3> Press the "SET" or "OK" button to exit, and the minimum temperature setting is complete.

Maximum temperature setting (heating mode):

1> Switch to "HEATING" mode, press and hold the "SET" button first, and then press the "F.Heat" button, after about 3 seconds, the temperature on the display starts to flicker and enter the environmentally friendly maximum temperature setting.

2> Press "TEMP▲" or "TEMP▼" button again and again, adjust to the required maximum temperature;

3 > Press the "SET" or "OK" button to exit, and the maximum temperature setting is complete.

Note: The factory default setting is 23 degrees for the minimum temperature in cooling mode and 23 degrees for the maximum temperature in heating mode.

Virtual temperature difference settings:
* Press and hold the "SET" button first, and then press the "A.SWING" button together, release when the temperature digit on the display flickers. Press the "TEMP▲" or "TEMP▼" button to set the temperature difference, the temperature difference range is 0-14 degrees. Press "OK" to confirm the setting. The default virtual temperature value is 3 degrees.

For example:
Under cooling mode, if the set minimum temperature is 23 degrees, virtual temperature value is 3 degrees, the minimum temperature displays on the remote will be 20 degrees, while the actual operating temperature of the A/C will remain at 23 degrees.

5. Child lock
By setting this function, code setting and temperature range limit functions will be locked.
Lock/Unlock: Press and hold "SET", and then press "TIME OFF" together for 3s to lock or unlock. When locked, "Lo" icon will display on the LCD; When unlocked, "nL" icon will display on the LCD.

---Restore To Factory Settings---

Press and hold "SET" button, then press "FAN" button for about 3 seconds, after the LCD screen is fully displayed, the remote control has been restored to factory Settings.

CODE

ACSON	990.
ADC	851.
AERMEC	000,020-039,600-609,720-739.
AICSON	040-059.
AIDELONG	293-295.
AIRTEK	775-779.
AIRWELL	000,020-039,180-199,230-239,500-550,950,960,962.
AITE	299-299.
AKIRA	796-797.
ALPIN	989-991,998.
AMCOR	501,508,509,532,973,978,979.
AMICO	982.
AMSTRAD	001-019,140-149,775-779.
AOKE	301-302.
AOLI	300.
APTON	852.
ARCO-AIR	140-149.
ARGO	000,020-039,230-239,282.
ARISTON	000,020-039,040-059,230-239.
ASHITA	140-149.
ASR	000,020-039.
AUCMA	213,216-228,933,967.
AURORA	040-059.
AUX	190-199,280-284,287,600-609.
AZUKI	001-019.
BAIXUE	299.
BALTUR	800-809.
BEIJINGJINGDIAN	304.
BEKO	000-059,180-199,882.
BENT	000-099,120-149,230-239.
BIG-THUMB	331.
BLUE STAR	057,550,887.
BOERKA	305-306,630.
BORLER	307.
BOSHI	310.
BOSHIGAO	308-309.
BOYIN	290.
BREEZE	090-099.
CAIXING	311.
CARRIER	040-059,598,890-899,990-999,178.
CASARTE	908.
CHANGFENG	190.
CHANGFU	835-838,874,907.
CHANGHONG	059-079,304-311,319,934,947.
CHANGLING	316-323.
CHENGYUAN	324.
CHIGO	090-099,245.
CHUANGHUA	325-328.
CHUANYAN	861.
CHUNLAN	171,174.
COLROLLA	851.
COMBINE	994.
CONROWA	337-341.
CONSUL	993.
CORONA	790-799.
CROWN	861.
DAEWOO	332-333.
DAIKIN	740-759,164,177,178,205,214,313,314,315,357.
DAITSU	000-059,230-239,600-609.
DAJINXING	329-330.
DAKE	851.
DAOTIAN	821-824.
DELCHI	050,680-689,990-999,979.
DELONGHI	000-039,120-149,106,460,900,922,960,968,984.
DIY	044,090,092,095.
DOCTOR	002,060,088,310,598,939.
DONGXIA	334-335.
DONGXINBAO	250-258.
DONGYANG	357,360.
DUNAN	336.
ECO AIR	000,020-039.
ECOFLAMCLIMA	548.
EKOKAI	000,020-039.
ELBA	439.
ELCO	982.
ELDLONG	293-295,861.
ELECTER	981-986.
ELECTRA	000,020-039,180-199,230-239,500.
ELECTROLINE	088.
ELECTROLUX	020-039,250,471-474,807,808,905,960.
EMAILAIR	000,020-039,180-199,500-550,860.
FANAIR	000,020-039.
FANTINI COSMI	000,020-039.
FEDDERS	978,929,938,939,964.
FEIEDRICH	979.
FEIGE	829-830,821.
FEILU	240-249,413.
FER-FERROLIT/FERROLIT	000-059,133,230-239,931.
FIRST	984.
FRESTECH	270-279,944,945.
FUJITECH	120-149.
FUJITHERMA	000,020-039.
FUJITSU	257,700-719.
FUNAI	246,248,258,267.
FUNIKI	992.
GALANZ	124-129,134-149,936-940.
GEER	342-343.
GENERAL	000,020-059,288,700-719,966.
GFORCE	053,064,845.
GLEE	280.
GMCC	C90,807,906.
GOLDSTAR	132,196,303,332,698,836.
GOODWEATHER	827.
GREE	C00,020-039,247,255,256,263,265,296,298.
GUANGDA	345-346.
GUANYUAN	997.
GUQIAO	344.
HAIER	C01-019,470,808.
HELTON	863.
HEMILTON	C14,088,095,125,126,127,128,151,159,226,587,845,848,882,924,936,937,948,949,966.
HERMANN	C01-019,040-059,080-099.
HICON	391-392.
HISENSE	230-239,066,161,212,320,411,648,850,913,927.
HITACHI	640-659,166,200,209,320.
HOKKAIDO	C40-059,060-099.
HONGYI	347.
HOWELL	C40-059,060-099.
HUABAO	101,102,108,348,819,865,960.
HUAGAO	348.
HUAKE	349-350,890.
HUALING	150-159,161,162,045,086,917.
HUAMEI	281,225,229,351-352,482,556,688,918.
HUANGHE	353.
HUAWEI	281,225,229,351-352,482,556,699,918.
HUIFENG	354-357,360.
HUIKANG	C88,592,623,624,951.
HYUNDAI	780-789,171,174.
INYCIN	475-483,826,858,859,910,923.
JOC	227,244,663,820,967.
JIALE	358.
JIANGNAN	359.
JINBEIJING	361-362.
JINDA	491-492.
JINSONG	183,363-365,270,370,915.
JINSTAR	360.
JOHNSON	282,681,976.
JUHUA	969.
KANGLI	368-370.
KELONG	110-119,230-239,814.
KLIMATAIR	797,798,799,800.
KOMECO	C40-059,060-099,140-149.
KONKA	366-367.
KRIS	804,805.
KT02-D001	283,284.
KTY001/2/3/4/5	285,286,287,288,289.
LEADER	921,971,973,994.
LENNOX	C00,020-039.
LENOIR	C80-099,120-149,230-239.
LG	C88,210,233,600-609.
LIANGYU	780-789.
LIKEAIR	386-387.
LILYTECH	918.
LITTLEDUCK	454-456.
LITTLESWAN	453,913,927.
LONGHE	861.
LOREN SEBO	C88,099,980,990,194,801-803.
LOREN-SEBO	980,990,194,801-803.
MAKATONY	C80-099.
MARIANI CLIMA	C01-019,600-609.
MCQUAY	790-795,151,698,774,937,952.
MEILING	388-391.
MICOM	C35.
MIDEA	C40-058,289,298-302.
MINGXING	290.
MITSUBISHI	163,166,167,169,170,551-599,827,909.
MITSUBISHI ELECTRIC	173,175,176.
MITSUKA	804.
MITSUSHITO	C00,020-039.
NATIONAL	660-689,038,223,241,902,970.
NEC	500-550,960,943,946.
NIKKO	810-811.
NISO	398-399,497.
NORCA	994.
NOTRIZ	858,923,963.
OGENERAL	659,717,718,719.
OLIMPIA SPLENDID	110-119,180-186,230-239,824.
OLYMPUS	995-996.
OPAL	997.
PANASONIC	660-689,122,201,203,204,205,215,312,902,970.
PANDA	464-466.
PEREG	998.
PHILCO	C01,106,110,821,907.
PHILIPS	287,411.
PILOT	802.
PINSHANG	290.
PROTON	C18,082,140,798,940.
PUYI	862.
QIXING	393.
RASONIC	970.
RAYBO	371-393.
RESTPOINT	C90.
RHOSS	547,905.
RICAI	394.
RIELLO	646.
RIJIANG	395-397.
ROADSTAR	140-159.
ROWA	393-395,036,101,911,928.
SABRO	151,197,240,235,865.
SACON	414.
SAJODENKI	188,389,390,391,695,812,813,816.
SAMPO	249,257,258,264,287,917.
SAMSUNG	510-529,202,351,914.
SANYO	500-550,640,941,960,969-971,673,676,916,920,924,943,946,105.
SANZUAN	190.
SAPORO	851.
SASAKI	195,620,911,912.
SAST	450-452.
SEKOM	154.
SENSOR	980.
SERENE	499.
SHAMEI	400.
SHANGLING	403-409,080,088,245,826,856,859,910,923.
SHANXING	401-402.
SHANYE	862.
SHARP/SAMPO	720-739,112,133,104,105,109,190,240,249,257,258,264,267,404,641,917,919,249,257,258,264,257,917.
SHENBAO	410-411.
SHENBAO	410-411.
SHENGFENG FEILU	412,413.
SHINCO	180-189,006,012,151,202,378.
SHINELCO	180-189,415.
SHINING	415.
SHUAIKANG	117,213.
SHUANGLU	241,416-418,798,797,948,948.
SIGMA	447.
SKYWORTH	325,326,397,877,397.
SOGO	291.
SONGGE	225,868,925.
SONGLINXIA	862.
SONGXING	419.
SOVA	101,102,292,420,811,980.
SOWA	962-963.
SOYEA	421-422.
SPEED	987.
SPLENDID	824.
SRTC	423.
STARIGHT-AIRCON	880.
SUMMER	859,910,990.
SUNBURG	817-820,235.
SUNDRUNG	260,268,894.
SWAN	439,866,913,914,827.
TADAIRAN	018,501,538,509,532,830,969,978,976,991.
TADIRAN	018,969,978.
TAIYA	862.
TASAKI	000,020-039,775-779.
TATUNG	037,158,242,243,664,666,667.
TCL	120-133,088,108,110,162,487,556-558,998.
TEAC	850-859,805.
TECNO MASTERS	551-599.
TECO	015,046,057,180,184,831-834,914.
TIANDI	435,608.
TIANJIN KONGTIAO	424.
TIANYUAN	425-428.
TOBO	250-258,915.
TONGLI	429-430.
TOSHIBA	830-839,100,107,172.
TOTALINE	548.
TOYO	825-828.
TRANE	551-599,812-816,922.
UNIAIR	836,009.
UNI-AIR	358-359,009,836.
UNICAL	000,020-059.
UTTLEDUCK	454-456,908.
VAILLANT	000-059,140-149,080-099.
VIDEOCON	597,627,628,629,884.
VKB	180.
VOLTAS	056,057,549,586,609,827,828,829.
VORTICE	000,180,020-039.
VORTIS	090-099,120-139,230-239.
WANBAO	431-433.
WANGZI	861.
WEILI	434-443,553-576.
WEITELI	444.
WHIRLPOOL	020,220-258,280-299,119,550-559,770-774,739,165.
WINIA	246,248.
WUFENG	445-446.
XIAOMI	321,322,324.
XILENG	448-449.
XINGHE	482-483.
XINHUABAO	290.
XINLE	457-460.
XINLING	461.
XIONGDI	862.
YAIR	013-015,044,457-471.
YAOMA	470,977.
YIDONG	499.
YONGXIN	918.
YORK	775-779,207,208,211.
YUETU	881-882,949.
YUTU	484-490.
ZEPHIR	108.
ZHONGYI	493-494.
ZUODAN	495.
OTHER	496,498,821-828,838-849,865-876,905-976,999.